

REDWALL Event Code Logger User Guide

Ver.4.0.0

Contents

1. Introduction.....	1
1.1. Compatible products	1
1.2. Software Requirements.....	1
2. How to use REDWALL Event Code Logger.....	2

1. Introduction

In this document, we will explain how to use “REDWALL Event Code Logger”. Using this software, you can get REDWALL Event Code and check it.

1.1. Compatible products


- RLS-3060 L/SH Version 1.0.0 or later.
- RLS-2020 Version 1.0.0 or later.
- PIE-1 Version 1.0.0 or later.

1.2. Software Requirements

- .Net Framework 4.5 or later.
-

2. How to use REDWALL Event Code Logger

1. Start the REDWALL Event Code Logger.



1. Enter target RLS-2020, RLS-3060 or PIE-1 IP address.
If you want to get R.E.C. that all detector sends, Check “View all REDWALL Event Code”.
2. Enter Port Number, and Select Protocol.
3. Click “Get Start” button, and enter path for saving R.E.C. log file.
If receives R.E.C., show it in “REDWALL Event Code”.