88

88

54

38

11

60

TOP

Touchless Switch_CleanSwitch_Device