

# **Optex Device Finder User Guide**

## Contents

1.	Introduction	1
1.1.	Compatible products	1
1.2.	Software Requirements	1
2.	How to use Optex Device Finder	2

### 1. Introduction

In this document, we will explain how to use "Optex Device Finder". Using this software, you can search Optex products in the same network.

#### 1.1. Compatible products

• RLS-2020 Version 2.1.0 or later.

### 1.2. Software Requirements

• .Net Framework 4.5 or later.



## 2. How to use Optex Device Finder

1. Start the Optex Device Finder.



Optex Device Finder.

- 1 Select network interface if you have multiple interfaces.
- 2 Change the text if you changed the user name for WEB page of REDSCAN mini.
- 3 Change the text if you changed the password for WEB page of REDSCAN mini.
- 4 Click "search" button.
- 5 Search result is shown in the list view.

#### Result:

🖳 Optex Device Finder —								
	Interface 192.168.0.210 V Search User REDSCAN Password *****							1.0.2
	IP Address 192.168.0.129	MAC Address 00-1f-d1-1e-02-3e	Model RLS-2020S	Version 2.1.0 (23Aug2018)	IP Type static			

To open top page of the device, double click the IP Address. Chrome browser will start and open the WEB page.