
## Active Infrared Door Sensor AIR-SLIDE 2


#### **Detection Area**



				unit : m
Α	2.00	2.30	2.50	3.00
В	0.13	0.16	0.17	0.21
C	0.38	0.46	0.50	0.60
D	0.71	0.86	0.94	1.13
Е	0.84	1.01	1.09	1.31
F	1.34	1.62	1.76	2.11
G	1.75	2.11	2.29	2.75
Н	0.92	1.11	1.20	1.45
-1	1.49	1.80	1.95	2.34
J	2.06	2.48	2.69	3.23

Charts show the values in the following area angle adjustment settings; Depth :0°

#### Dimensions



Specifications	
Model	AIR-SLIDE 2
Cover color	Black
Mounting height	2.0 m to 3.0 m
Detection area	See DETECTION AREA
Detection method	Active infrared reflection(*1)
Area angle adjustment	Depth:-8° to +8°
	Width: ±7°
	( 2 clicks with 3.5°every click-Left/Right )
FLEX EYE	Depth:-14° to +2°
angle adjustment	Width: ±42°
	(7 clicks with 6°every click-Left/Right)
Power supply (*2)	12 to 24 V AC ±10% (50 / 60 Hz)
	12 to 30 V DC ±10%
Power consumption	< 2.5 W (< 6 VA at AC)
Operation indicator	See Operation indicator table
Activation output	Form A relay
	50 V 0.3 A Max. (Resistance load)
Safety output	Form A relay
	50 V 0.3 A Max. (Resistance load)
Operating temperature	-35 to +55°C
Operating humidity	< 80%
Noise level	< 70 dBA
Output hold time	Approx. 0.5 sec.
Response time	< 0.3 sec.
IP rate	IP54
Weight	230 g
Accessories	1 Operation manual
	2 Mounting screws
	1 Mounting template
	1 Area adjustment tool
	1 Cable 3 m
	(8 × 0.22 mm <sup>2</sup> AWG24) (*3)

- \*1: BLUEZONE (1st row), 2nd and 3rd rows have a presence detection function.
- \*2 : When using this sensor, the sensor has to be connected to a door system which has the SELV circuit.
- \*3: Overcurrent protection with less than 2A.

#### Option







Unit: mm

#### Manufacturer / Asia sales Div.

#### OPTEX CO.,LTD.

5-8-12 Ogoto Otsu Shiga 520-0101 Japan TEL.: +81- (0) 77-579-8700 FAX.: +81- (0) 77-579-7030 WEBSITE: www.optex.co.jp/as/eng/index.html

#### North and South American Subsidiary

#### OPTEX Technologies Inc.

Corporate Headquarters

18730 S. Wilmington Ave. Suite 100 Rancho Dominguez, CA 90220 U.S.A.

TOLL-FREE: 800 877 6656 FAX.: +1 310 214 8655 WEBSITE: www.ot-inc.com

East Coast Office

8510 McAlpines Park Drive, Suite 108 Charlotte, NC 28211 U.S.A.

TOLL-FREE: 800 877 6656 FAX.: +1 704 365 0818

WEBSITE: www.ot-inc.com
European Subsidiary

#### OPTEX Technologies B.V.

Henricuskade 17, 2497 NB The Hague, The Netherlands
TEL::+31(0)70 419 41 00 FAX::+31(0)70 317 73 21 E-MAIL: info@optex.eu
WEBSITE: www.optex.eu

#### Thailand Subsidiary

#### OPTEX(THAILAND) CO., LTD.

90 Cyberworld Tower (Tower B) Unit B 1702 17th Flr., Ratchadaphisek Rd., Huai Khwang, Bangkok10310 Thailand

TEL.: +66-2-168-3162 FAX.: +66-2-168-3163



# Active Infrared Door Sensor with Built-in Touchless Switch AIR-SLIDE 2

Wave your hand Here to open door.











Copyright (C) 2016 OPTEX CO., LTD.

# No wiring, No contamination, No wasting energy. **Touch Free** Wave hand here to open door

## Active Infrared Door Sensor AIR-SLIDE 2

#### **Energy Saving**

Eliminates unwanted activations due to cross traffic to improve air conditioning efficiency.

#### Shop owner

I would like to avoid unnecessary door openings due to cross traffic to improve air conditioning efficiency. My shop is facing with a busy street.





#### **Germ Free**

Eliminates one of the only cross contamination points on a low energy or knowing act door.

#### Nurse

Touch switch is contamination points for a knowing act or low energy door.

I want to open a door without touching anything.





#### **Safety**

Provides safety throughout the threshold area keeping the door open until all people have moved away.

I want an automatic door for my kitchen but what I need is a limited detection area because my staff is walking around in front of a door.






#### FLEX EYE (knowing act detection area)



Blue zone Active infrared

This sensor is designed to detect a hand approaching to a touchless plate as a knowing activation device. FLEX EYE means an detection area for the hand detection.


When FLEXEYE mode is enabled, both FLEXEYE and 2nd to 4th row of detection area will detect passers.




#### Width angle adjustment


Depth angle adjustment












#### **BLUEZONE** technology



How it Works: When the approach area detects a person or object, the sensor will activate the door and turn on the "BLUEZONE" which detects through the threshold. As long as someone is in the detec -tion area, the sensor will keep the door in the open position. Once the area is cleared, the "BLUEZONE" will ignore the door panels and allow the door to safely close.




#### NO WIRING from the sensor to the touchless plate





## Active Infrared Door Sensor AIR-SLIDE T

#### **Detection Area**




reet,	incn	

Α	6'7" (2.00)	7'7" (2.30)	8'2" (2.50)	9'10" (3.00)
В	5" (0.13)	6" (0.16)	7" (0.17)	8" (0.21)
C	1'3" (0.38)	1'6" (0.46)	1'8" (0.50)	1'12" (0.60)
D	2'4" (0.71)	2'10" (0.86)	3'1" (0.94)	3'8" (1.13)
Ε	2'9" (0.84)	3'4" (1.01)	3'7" (1.09)	4'4" (1.31)
F	4'5' (1.34)	5'4" (1.62)	5'9" (1.76)	6'11" (2.11)
G	5'9" (1.75)	6'11" (2.11)	7'6" (2.29)	9' (2.75)
Н	3' (0.92)	3'8" (1.11)	3'11" (1.20)	4'9" (1.45)
-1	4'11" (1.49)	5'11" (1.80)	6'5" (1.95)	7'8" (2.34)
J	6'9" (2.06)	8'2" (2.48)	8'10" (2.69)	10'7" (3.23)

Charts show the values in the following area angle adjustment settings; Depth :0°

#### **Dimensions**



Specifications	
Model	AIR-SLIDET
Cover color	Black
Mounting height	6'7" (2.0 m) to 9'10" (3.0 m)
Detection area	See DETECTION AREA
Detection method	Active infrared reflection(*1)
Area angle adjustment	Depth:-8° to +8°
	Width: ±7°
	( 2 clicks with 3.5°every click-Left/Right )
FLEX EYE	Depth:-14° to +2°
angle adjustment	Width: ±42°
	( 7 clicks with 6°every click-Left/Right )
Power supply (*2)	12 to 24 V AC ±10% (50 / 60 Hz)
	12 to 30 V DC ±10%
Power consumption	< 2.5 W (< 6 VA at AC)
Operation indicator See Operation indicator table	
Test intput	Opto coupler
	Voltage / 5 to 30 V DC
	Current / 6 mA Max. (30 V DC)
Activation output	Form A relay
	50 V 0.3 A Max. (Resistance load)
Safety output	Form A relay
	50 V 0.3 A Max. (Resistance load)
Operating temperature	-31 to 131°F (-35 to +55°C)
Operating humidity	< 80%
Noise level	< 70 dBA
Output hold time	Approx. 0.5 sec.
Response time	< 0.3 sec.
IP rate	IP54
Weight	8.1 oz (230 g)
Accessories	1 Operation manual
	2 Mounting screws
	1 Mounting template
	1 Area adjustment tool
	1 Cable 9'10" (3 m)
	(8 × 0.22 mm <sup>2</sup> AWG24) (*3)

- $^{*}\mbox{1}$  : BLUEZONE (1st row), 2nd and 3rd rows have a presence detection function.
- \*2 : When using this sensor, the sensor has to be connected to a door system which has the SELV circuit.
- \*3 : Overcurrent protection with less than 2A.

#### Option



Touchless plate

#### Manufacturer / Asia sales Div.

#### OPTEX CO.,LTD.

5-8-12 Ogoto Otsu Shiga 520-0101 Japan TEL.: +81- (0) 77-579-8700 FAX.: +81- (0) 77-579-7030 WEBSITE: www.optex.co.jp/as/eng/index.html

#### North and South American Subsidiary

#### OPTEX Technologies Inc.

#### Corporate Headquarters

18730 S. Wilmington Ave. Suite 100 Rancho Dominguez, CA 90220 U.S.A.

TOLL-FREE: 800 877 6656 FAX.: +1 310 214 8655 WEBSITE: www.ot-inc.com

#### East Coast Office

8510 McAlpines Park Drive, Suite 108 Charlotte, NC 28211 U.S.A.
TOLL-FREE: 800 877 6656 FAX.: +1 704 365 0818
WEBSITE: www.ot-inc.com

#### **European Subsidiary**

#### OPTEX Technologies B.V.

Henricuskade 17, 2497 NB The Hague, The Netherlands
TEL::+31(0)70 419 41 00 FAX::+31(0)70 317 73 21 E-MAIL: info@optex.eu
WERSITE: www.ontex.eu



## Active Infrared Door Sensor with Built-in Touchless Switch

## AIR-SLIDE T

Wave your hand Here to open door.







walking across.







Copyright (C) 2016 OPTEX CO., LTD. No.77085-17376-02-1706

# No wiring, No contamination, No wasting energy. **Touch Free** Wave hand here to open door

#### **Energy Saving**

Eliminates unwanted activations due to cross traffic to improve air conditioning efficiency.

#### Shop owner

I would like to avoid unnecessary door openings due to cross traffic to improve air conditioning efficiency. My shop is facing with a busy street.





#### **Germ Free**

Eliminates one of the only cross contamination points on a low energy or knowing act door.

#### Nurse

Touch switch is contamination points for a knowing act or low energy door.

I want to open a door without touching anything.





#### Safety

Provides safety throughout the threshold area keeping the door open until all people have moved away.

I want an automatic door for my kitchen but what I need is a limited detection area because my staff is walking around in front of a door.





## Active Infrared Door Sensor AIR-SLIDE T


#### FLEX EYE (knowing act detection area)



This sensor is designed to detect a hand approaching to a touchless plate as a knowing activation device.

FLEX EYE means an detection area for the hand detection.

When FLEXEYE mode is enabled, both FLEXEYE and 2nd to 4th row of detection area will detect passers.



#### Width angle adjustment


#### Depth angle adjustment




















#### **BLUEZONE** technology



How it Works: When the approach area detects a person or object, the sensor will activate the door and turn on the "BLUEZONE" which detects through the threshold. As long as someone is in the detection area, the sensor will keep the door in the

open position. Once the area is cleared, the "BLUEZONE" will ignore the door panels and allow the door to safely close.



#### **NO WIRING from the sensor** to the touchless plate



Touchless plate

#### **Monitoring Capability**

AIR-SLIDE T has built-in "monitoring capability".

The AIR-SLIDE T monitors all its critical functions and notifies compatible

Self monitoring capability ensures a higher level of performance over the life of the sensor.

#### **Adapted in Cold District**

-31 to 131°F (-35 to +55°C)